




TERRA BASE FLOW PIPE

The Terra Base Flow Pipe, which supplies water to the inside of the Terra Base, is now available. Originally, the Terra Base was designed to grow plants by wrapping them around it and filling the inside with water, allowing irrigation through osmotic pressure. However, depending on the type of moss or plant, there were cases where the water flow was insufficient, making cultivation difficult. By connecting the Terra Base Flow Pipe to a Stream Pump Mini, water can be supplied and circulated within the Terra Base. This not only solves the water shortage issue for the plants but also adds a dynamic visual effect with water droplets trickling down the plants wrapped around the Terra Base, allowing for the enjoyment of not just plants but now water movement too.



Terra Base Flow Pipe 160



Please watch a video via the QR code.

Product Code	EAN Code	Product Name
152-610	4537934526109	Terra Base Flow Pipe 160
152-611	4537934526116	Terra Base Flow Pipe 230